

### Immediate Commands

Key	Normal	Shift	ALT
F1	Play Message 1	Record	N/A (not assigned)
F2	Play Message 2	Set WPM Speed	Set Lead-in Delay
F3	Play Message 3	Set HSCW Rate	Set Tail Delay
F4	Play Message 4	CW Practice	Set Serial Number
F5	Play Message 5	Toggle Farnsworth	Toggle Soft Sidetone
F6	Play Message 6	Toggle Sidetone	Toggle Bug Mode
F7	Play Message 7	Toggle XMIT Mute	Toggle Autospace
F8	Play Message 8	Toggle Tune	Toggle Iambic A/B
F9	Play Message 9	Quick Speed 1	Swap Paddles
F10	Play Message 10	Quick Speed 2	Adjust 1 <sup>st</sup> Bit Length
F11	Play Message 11	Quick Speed 3	Adjust Weighting
F12	Play Message 12	Quick Speed 4	Persistent Message
↑ UP	Speed +1 WPM	N/A	N/A
↓ DOWN	Speed -1 WPM	N/A	N/A
← LEFT	Dit/Dah Ratio-10%	N/A	Reduce Letterspace
→ RIGHT	Dit/Dah Ratio+10%	N/A	Increase Letterspace
PGUP	Sidetone Higher	N/A	Increase Sensitivity
PGDN	Sidetone Lower	N/A	Reduce Sensitivity
HOME	Reset Weight/Space	N/A	Status
TAB	Pause Transmit	N/A	A/D Diagnostic
ESC	Abort	N/A	N/A
INSERT	Pause Transmit	N/A	N/A

### Buffered Commands

CTL	Command	Syntax
C	Call Message	^CF1
D	Serial # -1	^D
H	Set HSCW	^Hnn nn=lpm/100
I	Serial #+1	^I
K	Key Down	^K
L	Load Loop Count	^Lnn nn=count
M	Merge Letters	^MAR
N	Play Serial#	^N
P	Pause	^P
S	Set Speed	^Snn nn=wpm
W	Wait	^Wnn nn=seconds
T	Load Timer	^Tnn nn=seconds
U	Key Up	^U
X	PTT On	^X
Y	PTT Off	^Y
Z	DECSZ Loop	^Z